



How To Configure AP Array Setup Tool?


AP Array Tool

Click **AP Array Setup Tool** to configure AP Array.



How To Configure AP Array Setup Tool?


Create AP Array



Please enter
Username and
Password to setup
AP Array

How To Configure AP Array Setup Tool?


Unconfigured AP



Wait for Scanning
Unconfigured AP in
LAN

How To Configure AP Array Setup Tool?


Unconfigure List



Unconfigured AP in
LAN will list in
Unconfigure AP field

How To Configure AP Array Setup Tool?

Role Selection




Drag Unconfigured AP to Member List

Select AP Array Role from drop-down box:
Master, Backup Master and Slave

How To Configure AP Array Setup Tool?

LAN Setting

LAN Setting can be Automatically configured for multiple APs.




Click Set IP to Auto Configure multiple APs

Fill in **Auto-Set-IP** column for multiple APs: IP Address, Subnet Mask and Gateway.

How To Configure AP Array Setup Tool?

LAN Setting

LAN Setting can be Manually configured .




Click Manually for
LAN Setting

Configure APs
Manually, please
enter an IP address,
Subnet Mask and
Gateway for AP LAN
Setting

How To Configure AP Array Setup Tool?


Basic Setting



Configure Basic
Settings for AP Array


How To Configure AP Array Setup Tool?

Complete!



How To Configure AP Array Setup Tool?

Modify AP Array




Choose Existing AP Array and enter AP Array password to modify settings

Click Modify Existing AP Array

How To Configure AP Array Setup Tool?

AP Array Status



Click Status to find existing AP Array status