


# Full HD 180° Outdoor Wi-Fi Camera

## Quick Start Guide



DCS-2670L





1



<https://eu.dlink.com/DCS-2670L>












2





3



4



OR



<https://www.dlink.com/support>



<https://eu.dlink.com/DCS-2670L>