



**Firmware Version:** V1.01  
**Prom Code Version:** N/A  
**Published Date:** 2015/06/30

---

### Content:

Upgrading Instructions:.....	2
New Features:.....	2
Problems Fixed: .....	2
Known Issues: .....	2
Related Documentation: .....	2

## Revision History and System Requirement:

Firmware Version	Date	Model	Hardware Version
V1.00	2015/06/16	DCS-4602EV	A1
V1.01	2015/06/30	DCS-4602EV	A1

## Upgrading Instructions:

Follow the steps below to upgrade the firmware:

1. Download the latest firmware file to your hard drive from the D-Link website.
2. Log-in camera web UI and go to **Maintenance/Firmware** web page upgrade
3. Locate the file (upgraded firmware) on your hard drive by clicking **Choose File**.
4. Click **Upload** to upgrade the firmware on your camera.

## New Features:

Fireware Version	New Features
	N/A

## Problems Fixed:

Firmware Version	Problems Fixed
V1.01.02	<ol style="list-style-type: none"> <li>1. Fixed no live video issue when image setting at 4:3, 1280x960 / 1024x768 resolution.</li> <li>2. Fixed flicking image when anti-flicker setting =50Hz</li> <li>3. Remove the SD card information on Event Setup help hints page.</li> </ol>

## Known Issues:

Firmware Version	Known Issues
	N/A

## Related Documentation:

N/A