






Quick Start Guide


DCS-4612EK
DCS-4614EK
DCS-4618EK




1




2




1




2




3




4




5




6




7




8




1




2




1




2




3



4





5



DCS-37-4

?



Model no.	DCS-37-4		DCS-37-5		DCS-37-6	
	Screw hole	Screw size	Screw hole	Screw size	Screw hole	Screw size
DCS-4612EK DCS-4614EK	-	-	B	PM4*8mm	B	PM4*10mm
DCS-4618EK	-	-	G	PM4*8mm	A	PM4*10mm
DCS-37-5	H	PM5*16mm	-	-	-	-
DCS-37-6	F	PM4*10mm	-	-	-	-



<https://www.dlink.com/warranty>



<https://eu.dlink.com/support>