

Due to technical specification of the DGS-1100-05PD & DGS-1100-05PDv2 following combination for PoE PD on Ports 1 & 2 are valid and working.

DGS-1100-05PD Pass Through PSE output[↵]

PD [↵]	PSE [↵]	
Port 5 Connected Device Type [↵]	Port 1 PD Class Type Support [↵]	Port 2 PD Class Type Support [↵]
IEEE802.3af PoE Switch or Injector [↵]	Class1 or 2 [↵]	NA [↵]
IEEE802.3af PoE Switch or Injector [↵]	NA [↵]	Class1 or 2 [↵]
IEEE802.3at PoE Switch or Injector [↵]	Class0 or 3 [↵]	NA [↵]
IEEE802.3at PoE Switch or Injector [↵]	NA [↵]	Class0 or 3 [↵]
IEEE802.3at PoE Switch or Injector [↵]	Class1 or 2 [↵]	Class1 or 2 [↵]

PoE PSE = PoE Power Supply
PoE PD = PoE Powered Device