
Unit Number 4	

01-Jan-2000 01:01:20 %INIT-I-InitCompleted: Initialization task is completed

>
>
>
>
>
>

## Power down and power on:



Stack menu [1] Show unit stack id [2] Set unit stack id [3] Back Enter your choice or press 'ESC' to exit: Enter unit stack id [0-6]: 0 Unit stack id updated to 0.

==== Press Enter To Continue ====