

Install rootCA on your dwc-x000

The screenshot shows the D-Link Unified Wireless Controller interface. The top navigation bar includes Status, Wireless, Network, Security, and Maintenance. The 'Security' tab is active, and the 'Trusted Certificates' sub-tab is selected. Below the navigation, there is a section for 'Trusted Certificates (CA Certificate) List'. A table displays one entry with the following details:

CA Identity (Subject Name)	Issuer Name
C=DE, ST=Hessen, L=Flaerheim, O=Indem.de/emailAddressadmin@indem.de, CN=opensee-ssl-ca	C=DE, ST=Hessen, L=Flaerheim, O=Indem.de/emailAddressadmin@indem.de, CN=opensee-ssl-ca

Below the table, there is a button labeled 'Upload New CA Certificate'.

Install client-cert on your dwc-x000

The screenshot shows the D-Link Unified Wireless Controller interface. The top navigation bar includes Status, Wireless, Network, Security, and Maintenance. The 'Security' tab is active, and the 'Active Self Certificates' sub-tab is selected. Below the navigation, there is a section for 'Active Self Certificates List'. A table displays one entry with the following details:

Name	Subject Name	Serial Number	Issuer Name	Expiry Time
DWC-1000-Home	CN=DWC-1000-Home	1 (0x1)	C=DE, ST=Hessen, L=Flaerheim, O=Indem.de/emailAddressadmin@indem.de, CN=opensee-ssl-ca	Nov 28 14:06:17 2022 GMT

Below the table, there is a button labeled 'Upload New Self Certificate'.

!! make the new cert the default setting !!

The screenshot shows the D-Link Unified Wireless Controller interface. The top navigation bar includes Status, Wireless, Network, Security, and Maintenance. The 'Security' tab is active, and the 'Active Self Certificates' sub-tab is selected. Below the navigation, there is a section for 'Active Self Certificates List'. A table displays one entry with the following details:

Name	Subject Name	Serial Number	Issuer Name
DWC-1000-Home	CN=DWC-1000-Home	1 (0x1)	C=DE, ST=Hesse

A context menu is open over the table entry, showing the following options:

- Select All
- Default
- Delete

Below the table, there is a button labeled 'Upload New Self Certificate'.

Login into dwc-x000 using https, here you can check the freshly installed cert

