

Quick Start Guide

G416C

4G LTE AX1500 Wi-Fi 6 Router



x1



x1




x1




x1



1 ,



2 ,



<https://eu.dlink.com/support>




GPL Information
<https://tsd.dlink.com.tw/GPL>



3 ,

2.4G SSID : G416C-XXXX
5G SSID : G416C-XXXX-5GHz
Wi-Fi password: XXXXXXXXXX




4 ,

<https://192.168.125.1>
Username: admin
Password: XXXXXXXXXX



3 ,



4 ,

<https://192.168.125.1>
Username: admin
Password: XXXXXXXXXX

