How to set up and install a DCS-XXXXLH

1   Preparation

On your mobile device, download mydlink Home by going to
mydlinkhomeapp.dlink.com, or by searching for **mydlink Home** in the iTunes App
Store.

Launch the mydlink Home app and create a new account or log in to your existing
account.

If you are asked about allowing the app to access your location, select **Allow**.

2   Installation

We recommend you to set up the Camera using the QR Code and WPS (2.1).
You should set up your camera manually, if you have difficulties installing it using the
QR-Code or your router is not supporting WPS (2.2):

2.1 Install using QR-Code and WPS

All devices should be in close proximity to each other during installation.

1.)

After logging in, tap the Settings icon ⚙ in the top-left corner, select Add New Device, and follow the Instructions.

2.)

Select "Scan QR Code" and Scan the QR Code from the info card

3.)

Power on your device.

Next

4.)

Wait for the Power LED to blink orange.

Next

5.)

6.)

If your router doesn't support WPS, select
Manual. (Goto Page 7 Step 7)

7.)

8.)

If the device is not connected, repeat this step.

9.)

Searching for your device...

10.)

Device Setup

Current Time Zone

Europe/Berlin

Change

Confirm

11.)

Device Setup

Give your device a nickname.

DCS-8200LH

Press below icon to change image.

Finish

Congratulations, your Panoramic HD
Camera is now ready to use!

2.2 Manual installation without QR Code/ WPS

1.)

2.)

Select Manual Setup

3.)

4.)

5.)

6.)

7.)

8.)

Select the DCS Network.

9.) Return to the myDlink Home App.

10.)

Press „Next".

11.)

12.)

13.)

14.)

Congratulations, your Panoramic HD Camera
is now ready to use!

15.)

16.)

To add more devices, press the gear at the top left.

Follow the steps as described in section 2.2

3 Troubleshooting

3.1 Error code 202

The error code 202, indicates that the device did not respond correctly.
To solve this issue, close the app and restart your phone.

3.2 Error code 425

The error code 425 indicates that the devices do not match the mydlink account. The mydlink Home World is separated into several „server rooms".
Each account and device is assigned to one of these „server

3.3 Hardware not found

1. The Device is not connceted to the WLAN
2. Your iOS device is not connceted to the WLAN

Solutions:

1. Can be checked by the LED on the device, it must be constantly green.
2. Must be checked in the device settings.