Firmware upgrading procedure for DI-714P+

Warning! : A firmware upgrade will normally erase all data and settings that are in your device. Please make sure that you backed-up your configuration before proceeding with the upgrading.

1) Key in the IP address of your device. If you have not changed the IP setting the address should be 192.168.0.1. Click on the Tools tab.

2) Once at the Tools tab, click on the Firmware icon on the side menu.

3) In the Firmware page, click on the Browse button to locate the firmware file.

4) Browse to the directory on your workstation where the firmware is located and select the firmware by double clicking on it.

5) Click on the Apply button to upgrade the firmware.

6) You will see a message reporting a successful upgrade.