

D-Link[®] Quick Installation Guide

DES-1316

Web Smart 16-Port 10/100Mbps
Switch with PoE



Before Your Begin

This Quick Installation Guide gives step-by-step instructions for setting up the D-Link DES-1316 PoE Web-Smart Switch. The model you have purchased may appear slightly different from those shown in the illustrations. For more detailed information about the Switch, its components, making network connections and technical specifications, please refer to the User's Manual on the master CD included with your switch.

Check Your Package Contents



Web Smart 16-Port 10/100Mbps Switch with PoE



CD-ROM(Containing manual and Utility Installation)



AC power cord (Suitable for your area's electrical power connections)

If any item is found missing or damaged, please contact your local reseller for replacement.


1 Setup The DES-1316 PoE Web Smart Switch

The setup of the Switch can be performed using the following steps:

- A. Install DES-1316 in a fairly cool and dry place. See Technical Specifications for the acceptable temperature and humidity operating ranges.
- B. Install the Switch in a site free from strong electromagnetic field generators (such as motors), vibration, dust, and direct exposure to sunlight.
- C. Leave at least 10cm of space at the front and rear of the hub for ventilation.
- D. Install the Switch on a sturdy, level surface that can support its weight, or in an EIA standard-size equipment rack. For information on rack installation, see the next section titled Rack Mounting.
- E. When installing the Switch on a level surface, attach the rubber feet to the bottom of each device. The rubber feet cushion the switch and protect the case from scratching.


2 Rack Mounting

The DES-1316 can be mounted in an EIA standard-size, 19-inch rack, which can be placed in a wiring closet with other equipment. Attach the mounting brackets at the Switch's front panel (one on each side), and secure them with the provided screws.



Combine the Switch with the provided screws

Then, use screws provided with the equipment rack to mount each Switch in the rack.



Mount the Switch in the rack

3

Connecting Network Cables

The DES-1316 supports 16 10/100M Ethernet ports and Port 1 ~ Port 8 are PoE enabled ports. These PoE ports are automatically activated when a compatible terminal is identified; the Switch will supply power through the Ethernet port to the connected PoE device.

For Legacy devices that are not yet compatible, the PoE port will not offer power to this device. This feature allows users to freely and safely mix legacy and Power over Ethernet compatible devices on their network.

The Switch supports 10Mbps Ethernet or 100Mbps Fast Ethernet and it runs both in half- and full- duplex mode using two pair of Category 5 cable.

These RJ45 ports are Auto-MDI type ports. The Switch can auto transform to MDI-II or MDI-X type, so you can make an easy connection without worrying if you are using a standard or crossover RJ45 cable.

4

AC Power

The Switch uses a 100-240V AC, 50-60 Hz power supply. The power switch is located at the rear of the unit adjacent to the AC power connector and the system fan. The Switch's power supply will adjust to the local power source automatically and may be turned on without having any or all LAN segment cables connected.


5

Identifying External Components

This chapter describes the front panel, rear panel, and LED indicators of the Switch.

Front Panel

The figure below shows the front panels of the Switch.



LED Indicator:

Comprehensive LED indicators display the status of the Switch and the network (see the LED Indicators chapter below).

PoE Ports (Ports 1~8):

These ports are PoE Enabled ports, the PoE port will automatically activate when a compatible terminal is identified, the Switch will supply power through the Ethernet port to the connected PoE device.

For Legacy devices that are not yet compatible, the PoE port will not offer power to this device. This feature allows users to freely and safely mix legacy and Power over Ethernet compatible devices on their network.

These ports support network speeds of either 10Mbps or 100Mbps, and can operate in half- and full- duplex transfer modes. These ports also support automatic MDI/MDIX crossover detection to give true “plug and play” capability. You just need to plug-in the network cable to the Switch directly, regardless of if the end node is a NIC (Network Interface Card) or a switch and a hub.


Ethernet Ports (Port 9~16):

These ports support network speeds of either 10Mbps or 100Mbps, and can operate in half- and full- duplex transfer modes. These ports also support automatic MDI/MDIX

crossover detection to give true “plug and play” capability. You just need to plug-in the network cable to the Switch directly, regardless of if the end node is a NIC (Network Interface Card) or a switch and a hub

Note: When the port is set to “Forced Mode”, Auto MDI/MDIX will be disabled.

Rear Panel



Rear panel of the Switch

AC Power Connector:

This is a three-pronged connector that supports the power cord. Plug in the female connector of the provided power cord into this connector, and the male into a power outlet. Supported input voltages range from 100-240V AC at 50-60Hz.

Reset:


The Reset button is to reset all settings back to the factory defaults.

Note: Be sure that you record the settings of your device, or else all the settings will be erased when pressing the “Reset” button.

6

Understanding LED Indicators

The front panel LEDs provide instant status feedback, and, help monitor and troubleshoot when needed.



LED indicators of the Switch

Power and CPU LEDs

POWER: Power Indicator

On	When the Power LED lights on, the Switch is receiving power.
Off	When the Power turns off or the power cord has an improper connection.

CPU: Management Indicator

Blinking	When the CPU is working, the CPU LED is blinking.
On/Off	The CPU is not working.

Ports 1~8 PoE port status LEDs

Link/ACT: Link/Activity

On	When the Link/ACT LED lights on, the respective port is successfully connected to an Ethernet network.
Blinking	When the Link/ACT LED is blinking, the port is transmitting or receiving data on the Ethernet network.
Off	There is no link.

100Mbps

On	When the 100Mbps LED lights on, the respective port is connected to a 100Mbps Fast Ethernet network.
Off	When the respective port is connected to a 10Mbps Ethernet network.

PoE Status

Green	When the PoE device is connected and the port supplies power successfully.
Red	When the following failure occurs on the PoE port: <ul style="list-style-type: none">✓ PoE power short circuit✓ PoE Power over current✓ PoE Power fault
Off	No Powered Device is detected.

Ports 9~16 Ethernet port status LEDs

Link/ACT: Link/Activity

On	When the Link/ACT LED lights on, the respective port is successfully connected to an Ethernet network.
Blinking	When the Link/ACT LED is blinking, the port is transmitting or receiving data on the Ethernet network.
Off	There is no link.

100Mbps

On	When the 100Mbps LED lights on, the respective port is connected to a 100Mbps Fast Ethernet network.
Off	When the respective port is connected to a 10Mbps Ethernet network

7

Installing the Web Management Utility

The following provides instructions guiding you through the installations of the Web Management utility.

1. Insert the Utility CD in the CD-ROM Drive.
2. From the **Start** menu on the Windows desktop, choose **Run**.
3. In the **Run** dialog box, type D:\Web Management Utility\setup.exe (D:\ depends where your CD-Rom drive is located) and click **OK**.
4. Follow the on-screen instructions to install the utility.
5. Upon completion, go to **Program Files -> web_management_utility** and execute the Web Management utility. (Figure 1.)




Figure 1. Web Management Utility

8

Configuring the Switch

The 8-Port 10/100Mbps Ethernet Web Smart Switch with 8-Port PoE has a Web GUI interface for smart switch configuration. The Switch can be configured through the Web Browser. A network administrator can manage, control, and monitor the Switch from the local LAN. This section indicates how to configure the Switch to enable its smart functions including:

- ◆ Port Settings (Speed/Duplex and Flow Control)
- ◆ VLAN Settings (802.1Q VLAN)
- ◆ Trunking
- ◆ Port Mirroring
- ◆ PoE Settings
- ◆ System Settings
- ◆ Device status and Statistics

Login

Before you configure this device, note that when the Web Smart Switch is configured through an Ethernet connection, the manager PC must be set on same the **IP network**. For example, when the default IP address of the Web Smart Switch is **192.168.0.1**, then the manager PC should be set at 192.168.0.x (where x is a number between 2 and 254), and the default subnet mask is 255.255.255.0.

Open Internet Explorer 5.0 or above Web browser.

Enter the IP address **http://192.168.0.1** (the factory-default IP address setting) into the address location. (Figure 2.)



Figure 2.

Through the Web Management Utility, you do not need to remember the IP Address. Select the device shown in the Monitor List of the Web Management Utility to settle the device on the Web Browser.

When the following dialog page appears, enter the default password **"admin"** and press Login to enter the main configuration window. (Figure 3.)

Login

System Name : DES-1316
 Location Name : TSD
 IP Address : 192.168.0.1
 MAC Address : 00-11-22-33-44-55

Password

Figure 3.

After entering the password, the main page appears and the screen will display the device status. (Figure 4.)

Building Networks for People

Express EtherNetwork

DES-1316

Setup

- [Port](#)
- [VLAN](#)
- [Trunking](#)
- [Mirror](#)
- [PoE](#)

Maintenance

- [Status](#)
- [Statistics](#)
- [System](#)
- [Trap](#)
- [Password](#)
- [Backup Setting](#)
- [Reset Setting](#)

Logout

Switch Status

Product Name	DES-1316
Firmware Version	1.00
Protocol Version	2.001.001
IP Address	192.168.0.1
Subnet mask	255.255.255.0
Default gateway	192.168.0.254
Trap IP	192.168.0.10
MAC address	00-11-22-33-44-55
System Name	DES-1316
Location Name	TSD
Login Timeout (minutes)	5
System UpTime	0 days 0 hours 24 mins 45 seconds

PORT Status

10/100 Mbps

ID	Speed	Flow Control	QOS	Link Status	ID	Speed	Flow Control	QOS	Link Status
01	Auto	Enable	Normal	100M Full	09	Auto	Enable	Normal	Down
02	Auto	Enable	Normal	Down	10	Auto	Enable	Normal	Down
03	Auto	Enable	Normal	Down	11	Auto	Enable	Normal	Down
04	Auto	Enable	Normal	Down	12	Auto	Enable	Normal	Down
05	Auto	Enable	Normal	Down	13	Auto	Enable	Normal	Down

Figure 4. Device Status

Setup Menu

When the main page appears, find the **Setup menu** on the left side of the screen (Figure 5). Click on the setup item that you want to configure. There are 12 options: *Port Settings*, *VLAN Settings*, *Trunk Settings*, *Mirror Settings*, *PoE Settings*, *Device Status*, *Statistics*, *System Settings*, *Trap Settings*, *Password Settings*, *Backup Settings*, and *Reset Settings* as shown in the Main Menu screen.



Figure 5.

Technical Support

You can find software updates and user documentation on the D-Link website.

D-Link provides free technical support for customers within the United States and within Canada for the duration of the warranty period on this product.

U.S. and Canadian customers can contact D-Link technical support through our website, or by phone.

Tech Support for customers within the United States:

D-Link Technical Support over the Telephone:

(877) 453-5465

Monday to Friday 6:00AM to 6:00PM PST

D-Link Technical Support over the Internet:

<http://support.dlink.com>

[email:support@dlink.com](mailto:support@dlink.com)

Tech Support for customers within Canada:

D-Link Technical Support over the Telephone:

(800) 361-5265

Monday to Friday 7:30am to 12:00am EST

D-Link Technical Support over the Internet:

<http://support.dlink.ca>

[email:support@dlink.ca](mailto:support@dlink.ca)

Tech Support for customers within the United Kingdom & Ireland:

D-Link UK & Ireland Technical Support over the Telephone:

+44 (0)845 612 0003 (United Kingdom)

+353 (0)12 421 061 (Ireland)

Monday to Friday 8:00 am to 10:00 pm

D-Link Technical Support over the Internet:

<http://www.dlink.co.uk>

D-Link®
Building Networks for People